

SLISTECH

Boost Control

Red/Yellow (+12V)

(GPO1) White/Black



Red/White (+5V)

(GPI1) Green/Black


Black (GND)

SLISTECH

4 Pin Relay - Mechanical

Fan/Device Positive

(GPO1) White/Black




Ignition (+12V)

Battery Red (+12V)

SLISTECH

5 P_{in} Relay - Mechanical



SLISTECH

Launch Control Switch



Uses Momentary
Switch

(GPI1) Green/Black

Red/White (+5V)

SLISTECH

Spinning Function Switch




Uses Momentary
Switch

(GPI1) Green/Black

Red/White (+5V)




Map Selector Switch



Note: This function will only work if fuel map selection is set to ECU Selected
Do **NOT** connect +12V to the GPI inputs


SLISTECH

N75 Solenoid Piping VI




SLUSTECH

N75 Solenoid Piping V2




SUSTECH

4 Cylinder Wasted Spark




SUSTECH

4 Cylinder Wasted Spark COP



SUSTECH


4 Cylinder Coil on Plug



Note: This function will only work when a home position sensor is present on a camshaft

SUSTECH

Lexus Twin Distributor



Note: This function will only work when a home position sensor is present on a camshaft



Sample Page to Copy

Uses SPST
Switch



(GPI1) Green/Black



Red/White (+5V)



Note: This function will only work if fuel map selection is set to ECU Selected